Failover preferred path not persistent after reboot

Published 04/22/2009

Symptom(s):

Device not on preferred path
Failover preferred path not persistent after reboot

Fact(s):

SGI Origin 3800
IRIX 6.5.30
SGI InfiniteStorage 4500 (IS4500)
/etc/failover.conf
SGIRDAC
Testing RAID Failover with "scsifo -t"

SGI Solution:

When using "scsifo -t" to test Failover, you may need to add disable_target_lun_check to the failover.conf file to trespass properly.

Answers others found helpful

- Alternative path failover not working
- How to setup failover2

Additional Details

Creation Date	04/22/2009 05:33 AM
Last modification	10/01/2015 02:21 AM
Published Date	04/22/2009
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Storage • Storage Servers • ISS3500 • ISS3124-RP2 • ISS3112-RP2 • ISS3104-RP10 • MIS 1.0 • JBOD Platforms • IS2245 • IS2224 • IS2212 • IS2125 • IS1124 • IS1116 • TP900 • RAID Platforms • NetApp Storage Arrays • IS220 • IS120 • DataDirect Networks (DDN) Storage Arrays • RM6700 • Legacy Storage • RAID Platforms • DataDirect Networks (DDN) Storage Array • RM660 • RM610 • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution